尺寸:130*130MM　100g双胶纸压 线



USER MANUAL



A.MOTHERBOARD

1.THE HOLES OF MOTHERBOARD SCREW ALIGN WITH THE HEXAGON PILLARS

2.FIX THE MOTHERBOARD AND CASE WITH MOTHERBOARD SCREW

3.CPU MAX H:165MM

MOTHERBOARD SPECIFICATIONS

ATX/MICRO ATX

B. VGA CARD

1.INSERT THE VGA CARD TO THE CARD SLOT OF MOTHERBOARD

2.FIX THE VGA CARD WITH SCREWS

3.RESERVING THE VGA CARD SLOTS FOR THE CASE

4.VGA MAX L:305MM

C.POWER SUPPLY

1.THE HOLES OF PSU ALIGN WITH THE RESERVED HOLE FOR CASE

2.FIX WITH THE SCREWS

D.HDD

1.SUPPORT HDD*1

2.THE SCREW HOLES OF HDD ALIGN WITH THEHDD HOLES,

LOCKED THE HDD SCREWHDD

E.SSD

1.SUPPORT SSD*1

2.THE HOLES OF SSD ALIGN WITH THE RESERVED HOLEFOR CASESSD

3.FIX SSD WITH THE MOTHERBOARD SCREWS

F LIQUID COOLER&FAN

1.FRONT:120mm*3

2.TOP:120mm*2

3.REAR:120mm*1

4.TOP OF THE POWER WAREHOUSE:120mm*2

Motherboard Compatiblility: ATX/Micro-ATX
I/O Ports:（Top）HD Audio,USB3.0*1,USB2.0*2
Drive bay: HDD*1(compatible *2);
SSD*1(Top of Power warehousecompatible 2)
Carton Dimensions: 500*245*445mm
Case Dimensions: : 380*190*447(Including foot pads)
Hareware Dimensions: 335*190*435mm
Front:120mmFan*3
Top:120mmFan*2
Rear:120mmFan*1
Top of the power warehouse:support120mmFan*2
PCI-E Expand the position: 7
Material thickness: 0.45mm
Max CPU Cooler Height: 165mm
Max VGA Length: 305mm